



▶▶▶ **PRINTING INSTRUCTIONS**

Instructions for the application onto **colored Candles, Ceramic and Glass** with Waterslide

2-PAPER-SYSTEM
for LED-Printers
with White Toner

▶ **PRINT SETTINGS**

ONLY FOR OKI PRINTERS WORKING WITH WHITE TONER

Paper & Print Setting: Transparent Foil, Multi Purpose-Tray

White Toner Darkness (Calibration in the Printer Menue): +3

Image Mode: Mirror Image, CMYK Mode (not RGB), Color Print, White On

▶ **TRANSFER APPLICATION**

BEFORE YOU START...

1. **Pre-heat** your heat press to make sure that the metal area of the lower plate is hot.
2. Please make sure, that the lower plate is not covered with a **teflon sheet**.

- ▶ Print the picture in mirror image on your A-paper.
- ▶ Place the Waterslide Paper on top of the lower plate and and place the A-Paper (printed side showing down) on the top of the Waterslide paper.
- ▶ Press all together at 180°C for 15-20 sec. with 2 bar (medium) pressure.
- ▶ Seperate the Waterslide from the A-Paper after it is **absolutely cold**.
- ▶ Cut off the picture as exactly as possible.
- ▶ Dip the picture around 30 seconds in water. The paper rolls up a little bit.
- ▶ Rub it carefully between the fingers in order to take off the carrier tape.
- ▶ Put the paper on the support and brush it with the fingers or a piece of plastic to avoid the bubbles of air.
- ▶ You will get a better result if you wipe off the water before letting dry three hours long.